



## ■ Installation de la pile ■ Instalación de las baterías

▪ **Vehicle** ▪ **Véhicule** ▪ **Vehículo**

- On / Off Switch
- Interrupteur On/Off
- Interruptor de Encendido/Apagado

## ■ Transmitter ■ Émetteur ■ Transmisor

- 

## **E GENERAL BATTERY SAFETY INFORMATION**

Read and follow operating instructions

- ## VEHICLE OPERATION

Any of the following conditions may interfere with the behavior and function.

The transmitter signals can easily be interrupted.

Improper handling may hamper the performance of the vehicle.

## SAFETY PRECAUTIONS

Remember to avoid water, heat, sand and high impact!

2. Users should keep strict accordance with the instruction manual while operating the product.

**FR** INFORMATIONS GÉNÉRALES DE SÉCURITÉ PILES

Lisez et suivez les instructions d'utilisation.

2. N'utilisez pas à la fois des piles alcalines, standard (carbone-zinc) ou piles rechargeables (nickel-cadmium).

## FONCTIONNEMENT DU VEHICULE

N'importe laquelle des circonstances suivantes peut altérer le fonctionnement et le comportement du véhicule. Il peut arriver facilement que les signaux de la radiocommande soient interrompus. La performance de votre véhicule peut être altérée par de mauvaises manipulations.

## PRECAUTIONS DE SECURITE

Rappel : évitez l'eau, la chaleur, le sable et les chocs violents!

1. Lisez le manuel d'exploitation complètement avant de jouer.